

INSTRUCTION

Model	Product	Code
Royal Enfield Interceptor 650 Royal Enfield Continental GT 650	Mask Scrabler	MCR-RE-SCRAB

You are advised to read the instructions carefully, before you proceed to any changes.

Any modifications on your motorcycle should be performed by specialized personnel, however the installation process of this product is quite easy if you follow the instructions below.



CONTENTS

- 1 X Plastic Mask
- 2 X metallic plate (inox L-RE-MCRSCRAB1 Pair)
- 2 X M6x18 (adapter)
- 2 X screws M6X10 (allen)
- 4 X screws M6X15 (allen-round head-washer)
- 4 X safety nuts M6
- 4 X washer 6x18
- 2 X washer 6x12





Unscrew the front end nuts that hold together the meter instruments, and in their position use the (M6X18) adaptors – as shown in the above photos 1 & 2.



Put the metallic plates in position as shown in the left hand photo.

Do no tighten them yet so that you can try on the mask and fit it in the right position before you tighten it in place.

3

1-2

1/2



Finally place the mask in position and gradually tighten the screws one by one along with the equivalent nuts.

You may still make any adjustments before you finalise your tightening in place.



The end result should appear as in the photo Thank you for choosing one of our products.